

# 35290 Yamaha Tracer 9 Infill Panels Fitting Instructions



## Kit Includes:

|    |          |                          |
|----|----------|--------------------------|
| 1X | C35290   | Infill Panels (pair)     |
| 6X | CBOL2180 | M8 X 10mm Stainless Bolt |

**Fitting this product to a Tracer with OEM pannier brackets?  
Use the original bolts - disregard the six that are supplied in this fitting kit.**

**Pyramid advise the use of thread-locking fluid for this product.**

Fitting these Pyramid infill panels is quick and simple.

- Use the 6 bolts supplied to attach the infill panels to the inside of the pillion footpegs. The larger infill panel should be fitted to the left hand side of the bike.
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



# 35290 Yamaha Tracer 9 Infill Panels Fitting Instructions



## Kit Includes:

|    |          |                          |
|----|----------|--------------------------|
| 1X | C35290   | Infill Panels (pair)     |
| 6X | CBOL2180 | M8 X 10mm Stainless Bolt |

**Fitting this product to a Tracer with OEM pannier brackets?  
Use the original bolts - disregard the six that are supplied in this fitting kit.**

**Pyramid advise the use of thread-locking fluid for this product.**

Fitting these Pyramid infill panels is quick and simple.

- Use the 6 bolts supplied to attach the infill panels to the inside of the pillion footpegs. The larger infill panel should be fitted to the left hand side of the bike.
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk



# 35290 Yamaha Tracer 9 Infill Panels Fitting Instructions



## Kit Includes:

|    |          |                          |
|----|----------|--------------------------|
| 1X | C35290   | Infill Panels (pair)     |
| 6X | CBOL2180 | M8 X 10mm Stainless Bolt |

**Fitting this product to a Tracer with OEM pannier brackets?  
Use the original bolts - disregard the six that are supplied in this fitting kit.**

**Pyramid advise the use of thread-locking fluid for this product.**

Fitting these Pyramid infill panels is quick and simple.

- Use the 6 bolts supplied to attach the infill panels to the inside of the pillion footpegs. The larger infill panel should be fitted to the left hand side of the bike.
- Check fixings periodically.

Any questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk

