



36160 Triumph Tiger 1200 Swingarm Protectors Fitting Instructions

Kit Includes:

2X	C36160	Swingarm Protectors
4X	CBOL0220	M6 x 25mm Flanged Bolts
4X	CWAS0230	M6 Washer
4X	CSPAM80002	Spacer

Pyramid advise the use of thread-locking fluid.

The Pyramid swingarm protectors are simple to fit. Remove the plastic pop rivets in the swingarm.

Attach the swingarm protectors as shown in the image below. Check fittings periodically.

Any questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!



36160 Triumph Tiger 1200 Swingarm Protectors Fitting Instructions

Kit Includes:

2X	C36160	Swingarm Protectors
4X	CBOL0220	M6 x 25mm Flanged Bolts
4X	CWAS0230	M6 Washer
4X	CSPAM80002	Spacer

Pyramid advise the use of thread-locking fluid.

The Pyramid swingarm protectors are simple to fit. Remove the plastic pop rivets in the swingarm.

Attach the swingarm protectors as shown in the image below. Check fittings periodically.

Any questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

